


T-TH01 USER Tablet Holder GUIDE



All information described in this user guide is based on the test standard of Takeway. Sorry for the inconvenience caused if there are any errors. The design and specifications of this product are subject to change without notice.

Copyrighted: All Rights Reserved



EHOMA INDUSTRIAL CORPORATION

TEL:04-2406 5031
info@takeway.tw
www.takeway.tw

TABLE EN 2014/03


T-TH01 USER Tablet Holder GUIDE

Before using the product for the first time, please read through the user guide.


Please use this product correctly after fully understanding the content of the user guide.

T-TH01 Table Holder is an accessory for Takeway ® T1 Clampod. T-TH01 can be used for tablets with sizes from 7" to 10.2". Before using the Tablet Holder, please install the base first, so that you can shoot in standing position at any time.

- 1 Loose the Quick release knob **A** of Takeway ® T1 and remove **B** Quick release clip.



- 2 Install T-TH01 Tablet Holder, screw in **B** Quick release clip on the back of the Tablet Holder with a coin or a flathead screwdriver. Screw in tightly, so that the Tablet Holder will not get loose.




T-TH01 USER GUIDE


Tablet Holder




- 3 Press the fasteners extending button and adjust fasteners **C** and **D** to a proper position. Place the Tablet close to the bottom of the Holder.
-




- 4 Press the **E** point of the top of the fastener **C** to fasten the Tablet. Please shake the Holder gently to make sure it was firmly fastened.
-



- 5 Choose a proper place of the jaw of **F**. Clamp the tripod on a proper location. After it is done, shake the clamp gently to make sure it is fixed tightly so that it will not drop.
-



- 6 Mount **B** Quick release clip with the Tablet on **G** Quick mounting platform and lock the clamp with **A** Quick release knob. When shooting, please use **H** ballhead knob to rotate the Tablet freely in 360 degree. Adjust the Tablet to a proper position and start shooting.
-



- 7 When using the Clampod in standing position, **H** ballhead knob can adjust the Tablet to a proper angle. Balance and collision of the clamp has to be kept and avoided so that no falling can be occurred.
-

